

Rodecaster View

Top View



- | | | |
|-----------------------|-----------------------------|--------------------------|
| 1 5.5" HD Touchscreen | 4 Channel Faders | 7 Rotary Encoder |
| 2 Record Button | 5 Listen and Mute Buttons | 8 SMART Pads |
| 3 Channel Buttons | 6 Headphone Output Controls | 9 Bank Switching Buttons |

Rear View



- | | | |
|---------------------|----------------------------------|--------------------------------|
| 1 Power Button | 4 USB 2 Input | 7 Ethernet Port |
| 2 microSD Card Slot | 5 1/4-inch Balanced Line Outputs | 8 1/4-inch Headphone Outputs |
| 3 USB 1 Input | 6 Dedicated USB Power Port | 9 XLR/TRS Neutrik Combo Inputs |